

Do not allow workers to

beams until they are full

installed and braced,

or serious injuries car

Never stack building

naterials over unsheath

braced beams or walls

hanger widths. If not, contact your supplier.

and supports for multiple-span joists must be level.

Leave a 1/16-inch gap between the I-joist end and a header.

they will remain in direct contact with concrete or masonry.

vertical alignment.

intermediate bearing

joists or I-joist blocking panels.

an I-joist-compatible depth selected.

separate underlayment layer is installed.

. Nail spacing & guidelines

greater than 3/12.

e substituted. For slopes greate

to resist lateral thrus


han 4/12 connectors are real


vide an ICC-ES Report (or similar) with approved application specification design values. Drywall screws can be brittle and should not be used.

14 gauge staples may be substituted for 8d (2-1/2") nails if staples penetrate the joist at least 1".

Except for cutting to length, never cut, drill, or notch I-joist flanges

Install I-joists so that top and bottom flanges are within ½ inch of true





or x-bridging.

Attach blocki

per 2b

x4 nailed to web

2") nails at 8" o.c. clinched


outrigger

top plate with nail si

and spacing used for re


sheathing edge nailin


around top flange of





RFPI® JOIST ALLOWABLE CLEAR SPANS - STANDARD TERM

wable spans shown are based on uniformly











## CODE REPORT INDEX

ROSEBURG EWP CODE REPORTS **PRODUCT** CCMC 13323-R I-JOIST LVL I-JOIST LVL & LVL Rim I-JOIST LVL & LVL Rim DSA PA-131 I-JOIST **DSA PA-136** LVL DSA AC 23-1 I-JOIST I-JOIST & LVL Florida FL2440

The code reports listed above are available at www.Roseburg.com, in the Engineered Wood Products section, Technical Information.

tel 800-347-7260 | fax 541-679-2612

RFPI®, RIGIDLAM®, RIGIDRIM®, RFP-KEYBEAM®, RFP-KEYPLAN®, SmartFramer™, Roseburg Framing System®, Quality Engineered Wood Products For Today's Builder® are trademarks of Roseburg Forest Products, Roseburg, Oregon.

©2020 Roseburg Forest Products

CCMC 13310-R ICC ESR-1251 ICC ESR-1210 City of Los Angeles RR 25439 City of Los Angeles RR 25680

Roseburg

A Forest Products Company

3660 Gateway Street | Springfield, OR 97477 web www.Roseburg.com | email ewpsales@rfpco.com